



Hardwood Closet Shelving

Installation Instructions: Drawers

NOTE: Always pre-drill holes before screwing into hardwood.

Unless the tower is sitting on the floor, make sure you have 2 tower support brackets underneath the tower before installing any drawers. If possible, screw down into the tower supports through the back of the tower bottom using #8 x 2" screws. Also, if you have not secured the tower sides to the underside of the top shelf by screwing down through the top shelf into the front tower side rails, do so now with #8 x 2 ½" screws. Be sure to pre-drill your holes.

1. Fully extend the drawer guide.
2. Remove the smallest section of the drawer guide by pushing down on the black plastic part labeled "push".
3. Screw the smallest section of the drawer guide onto the center of the drawer side with the small flat edge against the drawer face using the small screws (#8 x 7/16"). Repeat on the other side of the drawer.
4. Starting with the bottom drawer, screw the largest section of the drawer guide to the inside of the tower side rails at the appropriate height using the larger screws (#8 x 1"). Do not attempt to screw into a tower side slat.

Bottom Drawer - 10": Mark 4 ¾" up from top of tower bottom onto tower side rails.

8": Mark 3 ¾" up from top of tower bottom onto tower side rails.

6": Mark 2 ¾" up from top of tower bottom onto tower side rails.

Screw larger part of drawer glide on mark.

5. Insert the smallest section of the drawer guide into the larger section, thus setting the drawer in place.
6. Install the drawers one by one, working your way up. Measuring from the top of the installed drawer box below, make a mark on the tower side 5 5/8" (for a 10" drawer), 4 5/8" (for an 8" drawer), or 3 5/8" (for a 6" drawer) up, depending on the size drawer you are installing next. Screw the drawer guide into the tower side on that mark.

7. Screw shelf in place above the top drawer by screwing through the tower sides into the shelf.

Note: If two drawer towers are side by side, do one tower at a time so you can screw the shelf above the drawers in.

8. Screw the drawer faces onto the drawer boxes using the drawer handle screws provided.